

In-Situ Remediation (ISR-MT3DMSTM) Redox Zone Visualization

October 5, 2015




Porewater Solutions
Expertise • Experience • Innovation

ISR-MT3DMS Redox Zone Visualization

Introduction

- ISR-MT3DMS™ utilizes a unique visualization concept which makes it very easy to illustrate how redox zones are distributed in an aquifer
 - Typical models require plotting individual contour maps for each electron acceptor
 - This unique visualization approach uses only one contour map to illustrate relative concentrations of all electron acceptors and the outlines of each redox zone

Simulated TCE and Redox Zones: Plattsburgh AFB



LEGEND

● Primary Monitoring Well

— TCE Contours: 0.001, 0.01, 0.1, 1, and 10 mg/L




ISR-MT3DMS Redox Zone Visualization

Carey (2007)


Redox Zone Visualization

Note – variation in colors reflects change from background to low electron acceptor conc.




Example – Plattsburgh AFB (BTEX)

(a) Integrated-Depth Model



(b) Cross-Section Model



Note - BTEX concentration contours of 0.001, 0.01, 0.1, 1, and 10 mg/L.



Aerobic
Zone

Nitrate-Reducing
Zone



Iron-Reducing
Zone

Sulfate-Reducing
Zone

Methanogenic
Zone



Example – Plattsburgh AFB (TCE)



Note - TCE concentration contours of 0.001, 0.01, 0.1, 1, and 10 mg/L.



Aerobic
Zone

Nitrate-Reducing
Zone

Iron-Reducing
Zone

Sulfate-Reducing
Zone


Methanogenic
Zone




Transient Bioattenuation Capacity

Vejen Landfill, Denmark


$t = 1$ year



$t = 5$ years



$t = 15$ years



Porewater Solutions
Expertise • Experience • Innovation

ISR-MT3DMS Redox Zone Visualization

Carey (2001)


Example – Vejen Landfill, Denmark

Vertical dispersivity = 0.008 m

rate = 7.6e-3 per day

TOC degrades when TOC > 0.1 mg/L

Observed:



Model:

